465N-5606 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 PF1 PF2 PF3
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER STROBES
1	(ALL STROBES)	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DF1 ALTERNATES WITH PF1 DC ALTERNATES WITH PC (3 PULSES PER BURST)

Apply +12 vdc to power cable to activate.