465N-7208-0062 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER STROBES
1	ORG	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DF1 ALTERNATES WITH PF1 (3 PULSES PER BURST) DF4 ALTERNATES WITH PF4 (3 PULSES PER BURST) DC ALTERNATES WITH PC (5 PULSES PER BURST)
2	ORG & BLU (ARROW)	DF3, DF3 & DF2, DF2 & DF1, DF1 & PF1, PF1 & PF2, PF2 & PF3, PF3, DF4 & PF4, REPEAT WHILE DC ALTERNATES WITH PC (5 PULSES PER BURST)
3	ORG & WHT/BLK (ARROW)	PF3, PF3 & PF2, PF2 & PF1, PF1 & DF1, DF1 & DF2, DF2 & DF3, DF3, DF4 & PF4, REPEAT WHILE DC ALTERNATES WITH PC (5 PULSES PER BURST)
4	ORG & BLU & WHT/BLK (CENTER OUT)	DF1 & PF1, DF2 & DF1 & PF1& PF2, DF3 & DF2 & PF2 & PF3, DF3 & PF3, DF4 & PF4, REPEAT WHILE DC ALTERNATES WITH PC (5 PULSES PER BURST)

CONTROL WIRES FOR OPTIONAL HALOGEN LAMP

CONTROL WIRE ACTIVATED	HALOGEN LAMP
RED/WHITE	PF1 TAKEDOWN
or	
GRAY	DF1 TAKEDOWN

NOTES:

1. **GREEN control wire activates high intensity to strobes.**
2. **Apply +12vdc to appropriate control wire to activate desired function.**