465N-7208 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
1	ORG PREEMPTION FLASH RATE (OPTIONAL)	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DC & PC SIMULTANEOUS (6 PULSES PER BURST) DF4 ALTERNATES WITH PF4 (3 PULSES PER BURST) DF2 ALTERNATES WITH PF2 (3 PULSES PER BURST)
1	ORG & WHT/BLK	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DC & PC SIMULTANEOUS (6 PULSES PER BURST) DF4 ALTERNATES WITH PF4 (3 PULSES PER BURST) DF2 ALTERNATES WITH PF2 (3 PULSES PER BURST)

NOTE: GROUNDING the GREEN control wire activates low intensity to strobes.
Apply +12vdc to all other control wires to activate desired function.
For operation with a Tomar 940N-DCP or 940N-SIREN, use Profile N2.

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
RED/WHITE	PF1 (TAKEDOWN)
GRAY	DF1 (TAKEDOWN)

OPTIONAL STROBES

CONTROL WIRE ACTIVATED	STROBE LAMP
ORG	DF1 ALTERNATES WITH PF1
ORG & WHT/BLK	DF1 ALTERNATES WITH PF1