

# 465N-4004 FLASH PATTERN

## LIGHTBAR LAMP CONFIGURATION

DF2 DF1 PF1 PF2  
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
0	NONE	NONE
1	ORG	NONE
2	ORG & BLU	DF1 & PF1 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS
3	ORG & BLU & WHT/BLK	DF1 & PF1 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)

**NOTE: GREEN control wire activates high intensity to strobes.  
Apply +12vdc to appropriate control wire to activate desired function.**