

465NH-4805 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2
DF1L/DF1R
FCL/FCR
PF1L/PF1R
PF2

DC

PC

| MODE | CONTROL WIRES ACTIVATED | LAMP OPERATION FRONT / CORNER STROBES & HALOGENS |
|-------------|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | NONE | NONE |
| 1 | ORG | DF1L, FCR, PF1L SIMULTANEOUS ALTERNATES WITH DF1R, FCL, PF1R SIMULTANEOUS DF2 ALTERNATES WITH PF2 *DC ALTERNATES WITH PC* (*IF ORDERED WITH OPTIONAL STROBE OR HALOGEN) |
| RIGHT ARROW | BLU | DF1L, DF1L & DF1R, DF1L & DF1R & FCL, DF1L & DF1R & FCL & FCR, DF1L & DF1R & FCL & FCR & PF1L, DF1L & DF1R & FCL & FCR & PF1L & PF1R, REPEAT DF2 ALTERNATES WITH PF2 *DC ALTERNATES WITH PC* (*IF ORDERED WITH OPTIONAL STROBE) |
| LEFT ARROW | WHT/BLK | PF1R, PF1R & PF1L, PF1R & PF1L & FCR, PF1R & PF1L & FCR & FCL, PF1R & PF1L & FCR & FCL & DF1R, PF1R & PF1L & FCR & FCL & DF1R & DF1L, REPEAT DF2 ALTERNATES WITH PF2 *DC ALTERNATES WITH PC* (*IF ORDERED WITH OPTIONAL STROBE) |
| CENTER OUT | BLU & WHT/BLK | FCL & FCR, DF1R & FCL & FCR & PF1L, DF1L & DF1R & FCL & FCR & PF1L & PF1R, DF1L & DF1R & FCL & FCR & PF1L & PF1R, REPEAT DF2 ALTERNATES WITH PF2 *DC ALTERNATES WITH PC* (*IF ORDERED WITH OPTIONAL STROBE) |
| SWEEP | ORG & WHT/BLK | DF1L, DF1R & FCL, FCR & PF1L, PF1R, FCR & PF1L, DF1R & FCL, REPEAT DF2 ALTERNATES WITH PF2 *DC ALTERNATES WITH PC* (*IF ORDERED WITH OPTIONAL HALOGEN) |

NOTE: GREEN control wire activates high intensity to strobes.
 Apply +12vdc to appropriate control wire to activate desired function.
 Cut loop (22 AWG BLACK) on 930H-8A (halogen controller) to select low current arrow patterns.