

**950N1-3203 NEOBE LIGHTBAR**  
0045 - FACTORY SET FLASH PATTERN

Independent Switch application

**Mode 1**

+12 vdc **ORANGE** Control Wire Activated

Warning Lamps: *Outboard Simultaneous with Side & Corner - Neobe Flash Rate*

**Mode 2**

+12 vdc **BLUE** Control Wire Activated

Warning Lamps: *Outboard Alternate with Side & Corner - Neobe Flash Rate*

**Mode 3**

+12 vdc **ORANGE & BLUE** Control Wires Activated

Warning Lamps: *Outboard Alternate with Side & Corner - Neobe Flash Rate*

**Mode 4**

+12 vdc **WHT/BLK** or **(Org & W/B)** or **(Blue & W/B)** or **(Org & Blue & W/B)** Control Wire Activated

Warning Lamps: *Outboard Simultaneous with Side & Corner - Neobe Flash Rate*

**See 950N1-3203 Appendix A for additional 950N1-3203 Control & Power Wire functions.**

**Optional Feature that may be ordered:**

**Bonded Power Cable (Removes Control Cable) - Activates in Mode 4**