465N-4805-0050 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2 DF1 FC PF1 PF2
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
0	NONE	NONE
1	ORG (ALL STROBES)	DC & PC SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DF1, FC, PF1, FC, REPEAT (3 PULSES PER BURST)
2	BLU (RIGHT ARROW)	DC, DC & DF2, DF2 & DF1, DF1 & FC, FC & PF1, PF1 & PF2, PF2 & PC, PC, REPEAT
3	WHT/BLK (LEFT ARROW)	PC, PC & PF2, PF2 & PF1, PF1 & FC, FC & DF1, DF1 & DF2, DF2 & DC, DC, REPEAT
4	BLU & WHT/BLK (CENTER OUT)	FC, DF1 & FC & PF1, DF2 & DF1 & PF1 & PF2, DC & DF2 & PF2 & PC, DC & PC, REPEAT

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.