465N-7208-0101 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4
DC PC

CONTROL WIRES ACTIVATED	LAMP OPERATION
	FRONT / CORNER STROBES
ORG	PF4 ALTERNATES WITH PC (5 PULSES PER BURST)
BLU	DF4 ALTERNATES WITH DC (5 PULSES PER BURST)
ORG & BLU	DF4 & PF4 SIMULTANEOUS AND ALTERNATES WITH DC & PC SIMULTANEOUS (5 PULSES PER BURST)
WHT/BLK	DF3 & PF3 SIMULTANEOUS AND ALTERNATES WITH *DF1 & *PF1 SIMULTANEOUS (5 PULSES PER BURST)

***DF1 & PF1 are Optional Strobes**

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
GRAY	DF2 SCENE LIGHT
RED/WHITE	PF2 SCENE LIGHT
YEL	DF1 TAKEDOWN
BRN	PF1 TAKEDOWN

CONTROL WIRES FOR OPTIONAL ICC MARKER LIGHTS

CONTROL WIRE ACTIVATED	
BRN/WHT	ACTIVATE ICC MARKER LIGHTS

NOTES:

1. **GREEN control wire activates high intensity to strobes.**
2. **Apply +12vdc to appropriate control wire to activate desired function.**