465N-7208-0111 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4
DC PC

CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER STROBES
ORG	PF1 ALTERNATES WITH DF1 (5 PULSES PER BURST)
BLU	DC & PC SIMULTANEOUS AND ALTERNATES WITH DF4 & PF4 SIMULTANEOUS (5 PULSES PER BURST)
ORG & BLU	PF1, DC & PC SIMULTANEOUS AND ALTERNATES WITH DF1, DF4 & PF4 SIMULTANEOUS (5 PULSES PER BURST)
WHT/BLK	DF3 & PF3 SIMULTANEOUS AND ALTERNATES WITH *DF2 & *PF2 SIMULTANEOUS (5 PULSES PER BURST)

***DF2 & PF2 are Optional Strobes**

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	**HALOGEN LAMP**
GRAY	DF2 or *DF2L
RED/WHITE	PF2 or *PF2R
YEL	*DF2R
BRN	*PF2R

CONTROL WIRES FOR OPTIONAL ICC MARKER LIGHTS

CONTROL WIRE ACTIVATED	
BRN/WHT	ACTIVATE ICC MARKER LIGHTS

NOTES:

1. **GREEN control wire activates high intensity to strobes.**
2. **Apply +12vdc to appropriate control wire to activate desired function.**