465N-8810-0068 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF5 DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4 PF5
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
0	NONE	NONE
1	ORG & BLU	DF2 & PF2 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS DF5 & PF5 SIMULTANEOUS AND ALTERNATE WITH DF4 & PF4 SIMUTANEOUS
2	ORG & BLU & WHT/BLK	DF2 & PF2 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS DF5 & PF5 SIMULTANEOUS AND ALTERNATE WITH DF4 & PF4 SIMUTANEOUS DC ALTERNATES WITH PC

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	PF1	(TAKEDOWN)
BROWN	DF1	(TAKEDOWN)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.