465NH-7208-0089 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
0	NONE	NONE
1	ORG	DF4 ALTERNATES WITH PF4 (6 PULSES PER BURST) DF1 ALTERNATES WITH PF1 (3 PULSES PER BURST)

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
GRAY	PF3
RED/WHITE	DF3
YEL	PF2
BRN	DF2
WHT/BLK	DC & PC

CONTROL WIRES FOR OPTIONAL ICC MARKER LIGHTS

CONTROL WIRE ACTIVATED	
BRN/WHT	ACTIVATE ICC MARKER LIGHTS

NOTES:

1. **GREEN control wire activates high intensity to strobes.**
2. **Apply +12vdc to appropriate control wire to activate desired function.**